



INSTRUCTIONS FOR USE
Pro-Ject Switch Box

Dear music lover,

thank you for purchasing a PRO-JECT AUDIO input expander.

In order to achieve maximum performance and reliability you should study these instructions for use carefully.




Warning of a hazard for the user, the unit or possible misuse.



Important notice.

Connectors



Make all connections whilst the input expander is disconnected from the power supply.



Take care to connect the left and right channels correctly. The right channel is usually marked red, the left channel black or white.

Outputs

Out has to be connected to the **In 2** of the Pro-Ject Pre Box. **Out 2** can be used to connect a Pro-Ject headphone amplifier, like the Head Box II or the Head Box SE II.

Inputs

Line level sources such as CD player radio or TV can be connected to the input sockets marked **In 2 - In 5**.

Trigger

The socket marked **Trigger Switch** on the Pro-Ject Pre Box provides a trigger signal for the Switch Box. The trigger signal permits automatic synchronization with the input selector of the Pro-Ject Pre Box.

A 30cm long trigger cable is supplied with the Pro-Ject Switch Box for connecting the socket **Trigger Switch** on the Pro-Ject Pre Box and the socket **Trigger** on the back of the Pro-Ject Switch Box.

Do not use the trigger input and output for any other connections for which it is not designed.


Mains power connection

The unit is supplied with a power supply suitable for your country's mains supply. Check the label before connecting to ensure compliance with the mains rating in your house. Connect the low voltage plug from the power supply to the **Power ~16V** socket before connecting the power supply to the mains.

Selecting an input together with a Pro-Ject Pre Box

Pressing the **Input Select** button selects the **In 1** to **In 5** inputs in turn. Select the inputs using the remote control buttons marked **CH-** or **CH+**.

If Input **1** is selected, the LED over the **Input Select** button lights up green. If the inputs **2** to **5** are selected, it lights up red. The selected input will be shown by the corresponding LED on the Switch Box.



Selecting an input when used with an amplifier from another manufacturer.

Pressing the grey button on the front of the Switch Box selects the **In 2** to **In 5** inputs in turn. The selected input (**2** to **5**) will be shown by the corresponding LED on the Switch Box.



The dark grey button on the front of the Switch Box is without function when the Switch Box is connected to a Pro-Ject amplifier via the supplied connecting cable.

Technical specifications Pro-Ject Switch Box

Gain:	0dB
Line-level inputs:	1 pair RCA/Phono sockets, 3 x 3-pole 3,5mm co-axial jack
Line-level outputs:	1 pair RCA/Phono sockets, 3-pole 3,5mm co-axial jack
Trigger in:	3-pole 2,5mm co-axial jack
Outboard power supply:	16V/200mA AC, suitable for your country's mains supply
Power consumption:	16V/30mA AC
Dimensions (W x H x D):	103 x 38 x 120mm
Weight:	630g without power supply

Service

Should you encounter a problem which you are not able to alleviate or identify, please contact your dealer for further advice. Only when the problem cannot be resolved there should the unit be sent to the responsible distributor in your country.

Warranty



The manufacturer accepts no responsibility for damage caused by not adhering to these instructions for use. Modification or change to any part of the product by unauthorized persons release the manufacturer from any liability over and above the lawful rights of the customer.

PRO-JECT is a Registered Trademark of H. Lichtenegger.

This guide was produced by: Audio Trade GmbH
Copyright © 2008. All rights reserved.

The information was correct at the time of going to press. The manufacturer reserves the right to make changes to the technical specification without prior notice as deemed necessary to uphold the ongoing process of technical development.